

Dane aktualne na dzień: 01-05-2025 18:44

Link do produktu: <https://www.akcesoriapc.pl/bateria-movano-do-sony-bps13-czarna-p-5722.html>

Bateria Movano do Sony BPS13 (czarna)



Cena brutto	161,50 zł
Cena netto	131,30 zł
Dostępność	Dostępny
Numer katalogowy	7903
Kod EAN	5902687188246
Producent	Movano

Opis produktu

Bateria Movano do Sony BPS13 (czarna)

Nowa bateria z certyfikatem jakości CE, ROHS. Ogniwa litowo-jonowe firmy Zhuoneng. Bateria wyposażona jest w zabezpieczenie chroniące ją przed: przepięciem, przegrzaniem, zwarciem, przeciążeniem prądowym, głębokim rozładowaniem oraz przeładowaniem.

Numer produktu: BT/SO-BPS13B

Stan: nowyPojemność: 4400 mAh (49 Wh)Napięcie: 11.1V (10.8V)Ilosc_ogniw: 6 ogniw Li-IonMarka_ogniw:

ZhuonengZabezpieczenie_przed: przepięciem, przegrzaniem, zwarciem, przeciążeniem prądowym, głębokim rozładowaniem oraz przeładowaniemCertyfikat: CE, RoHSW_zestawie: bateria, instrukcja obsługi, karta gwarancyjnaGwarancja: 24 miesiące (obudowa i elektronika)

12 miesięcy (pojemność ogniw) Zamiennik: VGP-BPL13, VGP-BPL13/B, VGP-BPL13B, VGP-BPL21, VGP-BPS13, VGP-BPS13/A, VGP-BPS13/B, VGP-BPS13/Q, VGP-BPS13/S, VGP-BPS1321B, VGP-BPS13A, VGP-BPS13A/B, VGP-BPS13A/Q, VGP-BPS13A/R, VGP-BPS13A/S, VGP-BPS13AB, VGP-BPS13B, VGP-BPS13B/B, VGP-BPS13B/Q, VGP-BPS21, VGP-BPS21A, VGP-BPS21B

Zgodny z:

Sony:

seria Vaio: PCG-21313L, PCG-21313M, PCG-31311M, PCG-3C1M, PCG-3C6P, PCG-3D1M, PCG-3E5P, PCG-3F1M, PCG-3H1M, PCG-3J1M, PCG-61111M, PCG-7141M, PCG-7161M, PCG-7175P, PCG-7181M, PCG-7182M, PCG-7186M, PCG-81112M, PCG-81212M, PCG-8161M, SVE11113FXW, SVE11115FDB, SVE11115FDW, SVE11116FG, SVE11116FGP, SVE11116FW, SVE11119FJB, SVE11119FP, SVE11119FJW, SVE1111M1E, SVE1111M1EW, SVE11125CH, SVE11125CHP, SVE11125CV, SVE11125CVW, SVE11126CA, SVE11126CAB, SVE11126CF, SVE11126CFB, SVE11126CG, SVE11126CGB, SVE11126CV, SVE11126CVP, SVE1113M1EW, SVE111A11M, VGH-FW170J/H, VGN-AW110J, VGN-AW110J/H, VGN-AW110N, VGN-AW110N/H, VGN-AW11M/H, VGN-AW11S/B, VGN-AW11SR/B, VGN-AW11XU/Q, VGN-AW11Z/B, VGN-AW11ZR/B, VGN-AW120J, VGN-AW120J/H, VGN-AW125, VGN-AW125J/H, VGN-AW130J, VGN-AW130J/H, VGN-AW150, VGN-AW150Y, VGN-AW150Y/H, VGN-AW160J, VGN-AW160J/Q, VGN-AW170C, VGN-AW170Y, VGN-AW170Y/Q, VGN-AW180Y, VGN-AW180Y/Q, VGN-AW19, VGN-AW19/Q, VGN-AW190, VGN-AW1RXU/Q, VGN-AW215J, VGN-AW21M/H, VGN-AW21S/B, VGN-AW21SR/B, VGN-AW21VY/Q, VGN-AW21XY/Q, VGN-AW21Z/B, VGN-AW21ZR/B, VGN-AW220J, VGN-AW230J, VGN-AW230J/H, VGN-AW235J/B, VGN-AW270Y, VGN-AW270Y/Q, VGN-AW27GY, VGN-AW27GY/QE1, VGN-AW290, VGN-AW290JFQ, VGN-AW2XRY/Q, VGN-AW310J/H, VGN-AW31M/H, VGN-AW31S/B, VGN-AW31XY/Q, VGN-AW31ZJ/B, VGN-AW350J/B, VGN-AW35GJH, VGN-AW37GY/HE1, VGN-AW37GYQ, VGN-AW390, VGN-AW3XRY/Q, VGN-AW3ZRJ/B, VGN-AW41JF, VGN-AW41JF/H, VGN-AW41MF, VGN-AW41MF/H, VGN-AW41XH, VGN-AW41XH/Q, VGN-AW41ZF, VGN-AW41ZF/B, VGN-AW4MRF/H, VGN-AW4XRH/Q, VGN-AW4ZRF/B, VGN-AW50DB, VGN-AW50DB/H, VGN-AW51JGB, VGN-AW52JGB, VGN-AW53FB, VGN-AW70B/Q, VGN-AW71J, VGN-AW72J, VGN-AW73FB, VGN-AW80NS, VGN-AW80S, VGN-AW80US, VGN-AW81DS, VGN-AW81JS, VGN-AW81YS, VGN-AW82DS, VGN-AW82JS, VGN-AW82YS, VGN-AW83FS, VGN-AW83GS, VGN-AW83HS, VGN-AW90NS, VGN-AW90S, VGN-AW90US, VGN-AW91CDS, VGN-AW91CJS, VGN-AW91CYS, VGN-AW91DS, VGN-AW91JS, VGN-AW91YS, VGN-AW92CDS, VGN-AW92CJS, VGN-AW92CYS, VGN-AW92DS, VGN-AW92JS, VGN-AW92YS, VGN-AW93FS, VGN-AW93GS, VGN-AW93HS, VGN-AW93ZFS, VGN-AW93ZGS, VGN-AW93ZHS, VGN-BZ1,

VGN-BZ11EN, VGN-BZ11MN, VGN-BZ11VN, VGN-BZ11XN, VGN-BZ12EN, VGN-BZ12VN, VGN-BZ12XN, VGN-BZ13VN, VGN-BZ13XN, VGN-BZ153N, VGN-BZ153N/E1, VGN-BZ15GN, VGN-BZ16GN, VGN-BZ2, VGN-BZ21VN, VGN-BZ21XN, VGN-BZ26M, VGN-BZ26V, VGN-BZ26X, VGN-BZ31VT, VGN-BZ31XT, VGN-BZ560, VGN-BZ560CTO, VGN-BZ560N22, VGN-BZ560N24, VGN-BZ560N26, VGN-BZ560N30, VGN-BZ560N32, VGN-BZ560N34, VGN-BZ560P, VGN-BZ560P20, VGN-BZ560P22, VGN-BZ560P28, VGN-BZ560P30, VGN-BZ560P34, VGN-BZ561, VGN-BZ561N20, VGN-BZ561P20, VGN-BZ562NAB, VGN-BZ562P, VGN-BZ563P, VGN-BZ570NAB, VGN-BZAAFS, VGN-BZAAHS, VGN-BZAANS, VGN-BZAAPS, VGN-CS1, VGN-CS110E/S, VGN-CS11S/P, VGN-CS11S/Q, VGN-CS11S/W, VGN-CS11SR/P, VGN-CS11SR/Q, VGN-CS11SR/W, VGN-CS11Z/R, VGN-CS11Z/T, VGN-CS11ZR/R, VGN-CS11ZR/T, VGN-CS13H/P, VGN-CS13H/Q, VGN-CS13H/R, VGN-CS13H/W, VGN-CS13T/W, VGN-CS16T/P, VGN-CS16T/Q, VGN-CS16T/R, VGN-CS16T/T, VGN-CS16T/W, VGN-CS16Z, VGN-CS17H/Q, VGN-CS17H/W, VGN-CS19/P, VGN-CS19/Q, VGN-CS19/R, VGN-CS19/W, VGN-CS190, VGN-CS190EUP, VGN-CS190EUQ, VGN-CS190EUR, VGN-CS190EUW, VGN-CS190JTP, VGN-CS190JQT, VGN-CS190JTR, VGN-CS190JTT, VGN-CS190JTW, VGN-CS190JVQ/C, VGN-CS2, VGN-CS215J/Q, VGN-CS215J/R, VGN-CS21S/P, VGN-CS21S/R, VGN-CS21S/T, VGN-CS21S/V, VGN-CS21S/W, VGN-CS21Z/Q, VGN-CS220DP, VGN-CS220DQ, VGN-CS220DR, VGN-CS220DT, VGN-CS220DW, VGN-CS230J/Q, VGN-CS23G, VGN-CS23G/P, VGN-CS23G/Q, VGN-CS23G/W, VGN-CS23H, VGN-CS23H/B, VGN-CS23H/S, VGN-CS23T/Q, VGN-CS23T/W, VGN-CS25H, VGN-CS25H/C, VGN-CS25H/P, VGN-CS25H/Q, VGN-CS25H/R, VGN-CS25H/W, VGN-CS260DQ, VGN-CS260DW, VGN-CS26GW, VGN-CS26T/C, VGN-CS26T/P, VGN-CS26T/Q, VGN-CS26T/R, VGN-CS26T/T, VGN-CS26T/W, VGN-CS27, VGN-CS27/C, VGN-CS27/P, VGN-CS27/R, VGN-CS27/W, VGN-CS28, VGN-CS28/Q, VGN-CS280J/R, VGN-CS290JDB, VGN-CS290JEC, VGN-CS290JEP, VGN-CS290JEQ, VGN-CS290JER, VGN-CS290JEW, VGN-CS290NCB, VGN-CS290NFB, VGN-CS2CN1, VGN-CS3, VGN-CS310J/P, VGN-CS310J/Q, VGN-CS310J/R, VGN-CS31MR/P, VGN-CS31MR/W, VGN-CS31S/P, VGN-CS31S/Q, VGN-CS31S/R, VGN-CS31S/T, VGN-CS31S/V, VGN-CS31S/W, VGN-CS31SR/P, VGN-CS31SR/Q, VGN-CS31SR/V, VGN-CS31SR/W, VGN-CS31ST/P, VGN-CS31ST/Q, VGN-CS31ST/R, VGN-CS31ST/T, VGN-CS31ST/V, VGN-CS31ST/W, VGN-CS31Z/Q, VGN-CS31ZR/R, VGN-CS31ZR/T, VGN-CS320J/P, VGN-CS320J/Q, VGN-CS320J/R, VGN-CS320J/W, VGN-CS33H, VGN-CS33H/B, VGN-CS33H/Z, VGN-CS35GNB, VGN-CS36GJ/C, VGN-CS36GJ/I, VGN-CS36GJ/P, VGN-CS36GJ/Q, VGN-CS36GJ/R, VGN-CS36GJ/T, VGN-CS36GJ/U, VGN-CS36GJ/W, VGN-CS36GJJ, VGN-CS36H, VGN-CS36H/C, VGN-CS36H/P, VGN-CS36H/Q, VGN-CS36H/R, VGN-CS36H/W, VGN-CS36TJ/C, VGN-CS36TJ/J, VGN-CS36TJ/P, VGN-CS36TJ/Q, VGN-CS36TJ/R, VGN-CS36TJ/T, VGN-CS36TJ/U, VGN-CS36TJ/V, VGN-CS36TJ/W, VGN-CS385J/Q, VGN-CS385J/R, VGN-CS39, VGN-CS39/J, VGN-CS39/U, VGN-CS390, VGN-CS390JCP, VGN-CS390JCQ, VGN-CS390JCR, VGN-CS390JCW, VGN-CS390JDV, VGN-CS50B/W, VGN-CS51B/W, VGN-CS52JB/W, VGN-CS60B/P, VGN-CS60B/Q, VGN-CS60B/R, VGN-CS61B/P, VGN-CS61B/Q, VGN-CS61B/R, VGN-CS62JB/P, VGN-CS62JB/Q, VGN-CS62JB/R, VGN-CS71B/W, VGN-CS72JB/W, VGN-CS90HS, VGN-CS90NS, VGN-CS90S, VGN-CS91HS, VGN-CS91NS, VGN-CS91S, VGN-CS92DS, VGN-CS92JS, VGN-CS92XS, VGN-FW, VGN-FW11, VGN-FW11E, VGN-FW11ER, VGN-FW11J, VGN-FW11L, VGN-FW11LR, VGN-FW11M, VGN-FW11MR, VGN-FW11S, VGN-FW11SR, VGN-FW11Z, VGN-FW11ZRU, VGN-FW11ZU, VGN-FW130EW, VGN-FW130NW, VGN-FW139E/H, VGN-FW139EH, VGN-FW139NW, VGN-FW140E, VGN-FW140EH, VGN-FW140EW, VGN-FW140NW, VGN-FW145E, VGN-FW145E/W, VGN-FW145EW, VGN-FW150EW, VGN-FW15G, VGN-FW15T, VGN-FW160EH, VGN-FW17, VGN-FW17/B, VGN-FW170JH, VGN-FW17T/H, VGN-FW17W, VGN-FW180EH, VGN-FW19, VGN-FW19/B, VGN-FW190EBH, VGN-FW190EDH, VGN-FW198U, VGN-FW198UH, VGN-FW21, VGN-FW21E, VGN-FW21ER, VGN-FW21J, VGN-FW21L, VGN-FW21M, VGN-FW21MR, VGN-FW21SR, VGN-FW21Z, VGN-FW21ZL, VGN-FW25T/B, VGN-FW26T/B, VGN-FW27/B, VGN-FW27/W, VGN-FW27T/H, VGN-FW29B, VGN-FW290RB, VGN-FW290JT, VGN-FW290JTH, VGN-FW290JTW, VGN-FW290JVH, VGN-FW3, VGN-FW30B, VGN-FW31E, VGN-FW31J, VGN-FW31M, VGN-FW31Z, VGN-FW32J, VGN-FW33G/E1, VGN-FW33G/W, VGN-FW33GW, VGN-FW340DW, VGN-FW340J/H, VGN-FW350DH, VGN-FW355J/H, VGN-FW35F, VGN-FW35F/B, VGN-FW35F/W, VGN-FW35TJ/B, VGN-FW36TJ/B, VGN-FW373DW, VGN-FW378DH, VGN-FW378J/B, VGN-FW37J, VGN-FW37J/B, VGN-FW4, VGN-FW41E/H, VGN-FW41E/W, VGN-FW41ET/H, VGN-FW41J/H, VGN-FW41M/H, VGN-FW41MR/H, VGN-FW41ZJ, VGN-FW41ZJ/H, VGN-FW44MR, VGN-FW455J/B, VGN-FW455J/H, VGN-FW45GJB, VGN-FW45TJ/B, VGN-FW465J/B, VGN-FW465J/H, VGN-FW465J/T, VGN-FW46GJ/BE1, VGN-FW46GJB, VGN-FW46M, VGN-FW46S, VGN-FW46Z, VGN-FW47GYH, VGN-FW48E/H, VGN-FW490, VGN-FW490JEB, VGN-FW490JFT, VGN-FW4ZJR/H, VGN-FW4ZTJ/H, VGN-FW5, VGN-FW50B, VGN-FW51B/W, VGN-FW51JF/H, VGN-FW51MF, VGN-FW51MF/H, VGN-FW51ZF, VGN-FW51ZF/H, VGN-FW52JB, VGN-FW54E, VGN-FW54FB, VGN-FW54J, VGN-FW54M, VGN-FW54MR, VGN-FW54S, VGN-FW56E, VGN-FW56J, VGN-FW56M, VGN-FW56SR, VGN-FW56Z, VGN-FW56ZR, VGN-FW5ERF/H, VGN-FW5JTF/H, VGN-FW5MTF/H, VGN-FW5ZRF/H, VGN-FW5ZTF/H, VGN-FW70DB, VGN-FW71DB/W, VGN-FW72JGB, VGN-FW73JGB, VGN-FW74FB, VGN-FW81HS, VGN-FW81NS, VGN-FW81S, VGN-FW82DS, VGN-FW82JS, VGN-FW82XS, VGN-FW83DS, VGN-FW83JS, VGN-FW83XS, VGN-FW90, VGN-FW90HS, VGN-FW90NS, VGN-FW90S, VGN-FW91NS, VGN-FW91S, VGN-FW92DS, VGN-FW92JS, VGN-FW93DS, VGN-FW93JS, VGN-FW93XS, VGN-FW94FS, VGN-FW94GS, VGN-FW94HS, VGN-NS101E/L, VGN-NS101E/S, VGN-NS101E/W, VGN-NS105N/S, VGN-NS106E/S, VGN-NS10E/S, VGN-NS10J/S, VGN-NS10L/S, VGN-NS110E, VGN-NS110E/L, VGN-NS110E/S, VGN-NS110E/W, VGN-NS115N/S, VGN-NS11E/S, VGN-NS11ER/S, VGN-NS11J/S, VGN-NS11L/S, VGN-NS11M, VGN-NS11M/S, VGN-NS11MR/S, VGN-NS11S, VGN-NS11S/S, VGN-NS11SR/S, VGN-NS11Z/S, VGN-NS11ZR/S, VGN-NS120E, VGN-NS120E/L, VGN-NS120E/S, VGN-NS120E/W, VGN-NS12M/S, VGN-NS12M/W, VGN-NS130E, VGN-NS130E/L, VGN-NS130E/S, VGN-NS130E/W, VGN-NS135E, VGN-NS135E/L, VGN-NS135E/S, VGN-NS135E/W, VGN-NS140E, VGN-NS140E/L, VGN-NS140E/S, VGN-NS140E/W, VGN-NS150J, VGN-NS150J/L, VGN-NS150J/S, VGN-NS150J/W, VGN-NS15G/S, VGN-NS15H/S, VGN-NS160E, VGN-NS160E/L, VGN-NS160E/S, VGN-NS160E/W, VGN-NS180E, VGN-NS180E/L, VGN-NS180E/S, VGN-NS180E/W, VGN-NS190J, VGN-NS190J/L, VGN-NS190J/S, VGN-NS190J/W, VGN-NS20E/P, VGN-NS20E/S, VGN-NS20J/S, VGN-NS20M/S, VGN-NS20S/S, VGN-NS20Z/S, VGN-NS21E/S, VGN-NS21ER/S, VGN-NS21M/P, VGN-NS21M/S, VGN-NS21M/W, VGN-NS21S, VGN-NS21S/S, VGN-NS21S/W, VGN-NS21SR/S, VGN-NS21X/S, VGN-NS21Z, VGN-NS21Z/S, VGN-NS230DP, VGN-NS230DW, VGN-NS230E, VGN-NS235J/L, VGN-NS235J/P, VGN-NS235J/S, VGN-NS235J/W, VGN-NS240DP, VGN-NS240DS, VGN-NS240DW, VGN-NS240E/L, VGN-NS240E/P, VGN-NS240E/S, VGN-NS240E/W, VGN-NS255DS, VGN-NS255J/S, VGN-NS25G/E1, VGN-NS25G/P, VGN-NS25G/S, VGN-NS25GP, VGN-NS290J/L, VGN-NS290J/S, VGN-NS30E/P, VGN-NS30E/S, VGN-NS30E/W, VGN-NS30Z/S, VGN-NS31EH/S, VGN-NS31ER/S, VGN-NS31M/P, VGN-NS31M/S, VGN-NS31M/W, VGN-NS31MR/S, VGN-NS31MT/S, VGN-NS31S, VGN-NS31S/S, VGN-NS31ST/S, VGN-NS325J, VGN-NS328J/S, VGN-NS330J/L, VGN-NS330J/P, VGN-NS330J/S, VGN-NS36E, VGN-NS38E, VGN-NS38E/S, VGN-NS38M/P, VGN-NS38M/S, VGN-NS38M/W, VGN-NS50B/L, VGN-NS50B/W, VGN-NS51B, VGN-NS51B/L, VGN-NS51B/P, VGN-NS51B/W, VGN-NS52JB, VGN-NS52JB/L, VGN-NS52JB/P, VGN-NS52JB/W, VGN-NS70B, VGN-NS70B/W, VGN-NS71B, VGN-NS71B/W, VGN-NS72JB, VGN-NS72JB/W, VGN-NS90HS, VGN-NS92JS, VGN-NS92XS, VGN-NW, VGN-NW11S/S, VGN-NW11S/T, VGN-NW11S/T, VGN-NW11S/T, VGN-NW11SR/S, VGN-NW11Z/S, VGN-NW11Z/T, VGN-NW11ZR/S, VGN-NW120J/S, VGN-NW120J/W, VGN-NW12Z/S, VGN-

NW12Z/T, VGN-NW130J/S, VGN-NW130J/T, VGN-NW130J/W, VGN-NW13GH/T, VGN-NW15, VGN-NW150J/S, VGN-NW150J/T, VGN-NW150J/W, VGN-NW15G, VGN-NW15G/T, VGN-NW15GT, VGN-NW160J/S, VGN-NW160J/W, VGN-NW17GJ/S, VGN-NW17GJS, VGN-NW180J/S, VGN-NW20EF/P, VGN-NW20EF/S, VGN-NW20EF/W, VGN-NW20SF/P, VGN-NW20SF/S, VGN-NW20ZF/S, VGN-NW20ZF/T, VGN-NW21EF, VGN-NW21EF/S, VGN-NW21JF, VGN-NW21JF/S, VGN-NW21MF, VGN-NW21MF/P, VGN-NW21MF/S, VGN-NW21MF/W, VGN-NW21SF, VGN-NW21SF/S, VGN-NW21SF/T, VGN-NW21ZF, VGN-NW21ZF/S, VGN-NW21ZF/T, VGN-NW240F, VGN-NW24EG, VGN-NW24JG, VGN-NW24MG, VGN-NW24MR, VGN-NW24S, VGN-NW250F/B, VGN-NW250F/S, VGN-NW250F/T, VGN-NW250F/W, VGN-NW26E, VGN-NW26EG, VGN-NW26JG, VGN-NW26M, VGN-NW26MRG, VGN-NW280F, VGN-NW280F/S, VGN-NW280F/T, VGN-NW2ERE/S, VGN-NW2ETFS, VGN-NW2MRE/P, VGN-NW2MRE/S, VGN-NW2MTF/S, VGN-NW2SRF/S, VGN-NW2STF/T, VGN-NW2ZRF/N, VGN-NW31EF, VGN-NW31EF/S, VGN-NW31EF/W, VGN-NW31JF, VGN-NW31JF/S, VGN-NW320F/B, VGN-NW320F/TC, VGN-NW35E, VGN-NW35E/B, VGN-NW35E/P, VGN-NW35E/W, VGN-NW380F/S, VGN-NW380F/T, VGN-NW50JB, VGN-NW51FB, VGN-NW51FB/N, VGN-NW51FB/W, VGN-NW70JB, VGN-NW71FB, VGN-NW71FB/N, VGN-NW71FB/W, VGN-NW91FS, VGN-NW91GS, VGN-NW91VS, VGN-P710T/B, VGN-P710T/G, VGN-P710T/R, VGN-P710T/W, VGN-P730A/G, VGN-P730A/N, VGN-P730A/Q, VGN-P730A/R, VGN-P730A/W, VGN-SR11M, VGN-SR11MR, VGN-SR12G/B, VGN-SR12G/P, VGN-SR12G/S, VGN-SR13, VGN-SR13/B, VGN-SR130EB, VGN-SR130EP, VGN-SR130ES, VGN-SR130NB, VGN-SR13GN/B, VGN-SR13GN/P, VGN-SR13GN/S, VGN-SR140E/S, VGN-SR140EB, VGN-SR140EP, VGN-SR140ES, VGN-SR140NS, VGN-SR150FN, VGN-SR16, VGN-SR16/P, VGN-SR16/S, VGN-SR165E/B, VGN-SR165E/P, VGN-SR165E/S, VGN-SR165EB, VGN-SR165EP, VGN-SR165ES, VGN-SR165NB, VGN-SR175N/B, VGN-SR175NB, VGN-SR18/J, VGN-SR18/Q, VGN-SR190EBJ, VGN-SR190EBQ, VGN-SR190F, VGN-SR19VN, VGN-SR19VRN, VGN-SR19XN, VGN-SR21MS, VGN-SR21RM/H, VGN-SR21RM/S, VGN-SR220J, VGN-SR220J/B, VGN-SR220J/H, VGN-SR230J, VGN-SR23H/B, VGN-SR240J/B, VGN-SR240N/B, VGN-SR25G/B, VGN-SR25G/P, VGN-SR25G/S, VGN-SR25M/B, VGN-SR25S/B, VGN-SR25T/P, VGN-SR25T/S, VGN-SR26/B, VGN-SR26/P, VGN-SR26/S, VGN-SR26GN/B, VGN-SR26MN/B, VGN-SR27TN/B, VGN-SR28/B, VGN-SR28/J, VGN-SR28/Q, VGN-SR290JTH, VGN-SR290JTJ, VGN-SR290JTO, VGN-SR290JV/C, VGN-SR290JVH/C, VGN-SR290NTB, VGN-SR29VN/S, VGN-SR29XN/S, VGN-SR2RVN/S, VGN-SR3, VGN-SR31M/S, VGN-SR33H, VGN-SR33H/B, VGN-SR33H/P, VGN-SR33H/S, VGN-SR35G/B, VGN-SR35G/E1, VGN-SR35G/P, VGN-SR35G/S, VGN-SR35M/B, VGN-SR35T/B, VGN-SR35T/P, VGN-SR35T/S, VGN-SR36GNS, VGN-SR36MN/B, VGN-SR36MN/P, VGN-SR37M, VGN-SR37TN/B, VGN-SR38, VGN-SR38/B, VGN-SR38/J, VGN-SR38/Q, VGN-SR390NAB, VGN-SR390NAH, VGN-SR39D, VGN-SR39D/J, VGN-SR39D/Q, VGN-SR39VN/S, VGN-SR39XN/S, VGN-SR3CW/B, VGN-SR3S1, VGN-SR4, VGN-SR410J/B, VGN-SR41M/P, VGN-SR41M/S, VGN-SR41M/W, VGN-SR420J/B, VGN-SR430J/B, VGN-SR43G/B, VGN-SR43G/N, VGN-SR43G/P, VGN-SR43G/W, VGN-SR43S/B, VGN-SR43S/P, VGN-SR45G/B, VGN-SR45G/G, VGN-SR45G/N, VGN-SR45G/P, VGN-SR45H, VGN-SR45H/B, VGN-SR45H/N, VGN-SR45H/P, VGN-SR45M/B, VGN-SR45M/P, VGN-SR45T/B, VGN-SR45T/P, VGN-SR45T/W, VGN-SR46GD, VGN-SR46GD/B, VGN-SR46GD/P, VGN-SR46GDB, VGN-SR46MD/B, VGN-SR46SD/B, VGN-SR46SD/P, VGN-SR46TD/B, VGN-SR46Z, VGN-SR48J, VGN-SR48J/B, VGN-SR48J/J, VGN-SR490, VGN-SR490JCN, VGN-SR490JCP, VGN-SR49D, VGN-SR49D/J, VGN-SR49D/Q, VGN-SR49VN/H, VGN-SR49VT/H, VGN-SR49XN/H, VGN-SR4MR/P, VGN-SR4MR/S, VGN-SR4MR/W, VGN-SR4VR/H, VGN-SR5, VGN-SR51B, VGN-SR51B/P, VGN-SR51B/S, VGN-SR51MF, VGN-SR51MF/P, VGN-SR51MF/S, VGN-SR51MF/W, VGN-SR51RF/P, VGN-SR51RF/S, VGN-SR51RF/W, VGN-SR53GF/B, VGN-SR53GF/N, VGN-SR53GF/P, VGN-SR53GF/W, VGN-SR53SF/B, VGN-SR53SF/P, VGN-SR55GF/B, VGN-SR55GF/N, VGN-SR55GF/P, VGN-SR55MF/B, VGN-SR55TF/B, VGN-SR55X, VGN-SR56GG/B, VGN-SR56GG/S, VGN-SR56MG/B, VGN-SR56SG/B, VGN-SR56SG/P, VGN-SR56XN, VGN-SR57S, VGN-SR57V, VGN-SR57X, VGN-SR59TG/H, VGN-SR59VG, VGN-SR59VG/H, VGN-SR59XG/H, VGN-SR70B, VGN-SR70B/S, VGN-SR72B/P, VGN-SR72B/S, VGN-SR73JB, VGN-SR73JB/S, VGN-SR74FB, VGN-SR74FB/S, VGN-SR90FS, VGN-SR90NS, VGN-SR90S, VGN-SR90US, VGN-SR91NS, VGN-SR91PS, VGN-SR91S, VGN-SR91US, VGN-SR92NS, VGN-SR92PS, VGN-SR92S, VGN-SR92US, VGN-SR93DS, VGN-SR93JS, VGN-SR93PS, VGN-SR93YS, VGN-SR94FS, VGN-SR94GS, VGN-SR94HS, VGN-SR94VS, VGN-TX15C/W, VGN-TX16C/B, VGN-TX16C/W, VGN-TX17C/B, VGN-TX17C/L, VGN-TX25C/W, VGN-TX26C/B, VGN-TX26C/T, VGN-TX26C/W, VGN-TX27CP/B, VGN-TX27CP/L, VGN-TX28CP/L, VGN-TX36C/B, VGN-TX36C/T, VGN-TX36C/W, VGN-TX37CP/B, VGN-TX37CP/L, VGN-TX38CP/L, VGN-TX45C/B, VGN-TX46C/B, VGN-TX46C/T, VGN-TX46C/W, VGN-TX47CP/B, VGN-TX47CP/L, VGN-TX48CP/L, VGN-TX56C/B, VGN-TX56C/T, VGN-TX56C/W, VGN-TX57CN, VGN-TX58CN, VPC-18EC/P, VPC-B119GJ, VPC-B119GJ/B, VPC-B11AGJ, VPC-B11AV, VPC-B11AVJ, VPC-B11V9E, VPC-B11V9E/B, VPC-B11X9E, VPC-B11X9E/B, VPC-CW12EN/BU, VPC-CW12ES/BU, VPC-CW13EG/BU, VPC-CW13FX/R, VPC-CW152C, VPC-CW152C/B, VPC-CW152C/W, VPC-CW15EC/BU, VPC-CW15EC/WU, VPC-CW15FA/B, VPC-CW15FA/P, VPC-CW15FA/W, VPC-CW15FG, VPC-CW15FG/B, VPC-CW15FG/P, VPC-CW15FG/W, VPC-CW15FN/R, VPC-CW16EC, VPC-CW16EC/B, VPC-CW16EC/L, VPC-CW16EC/P, VPC-CW16EC/R, VPC-CW16EC/W, VPC-CW16FA/B, VPC-CW16FA/L, VPC-CW16FA/P, VPC-CW16FA/R, VPC-CW16FA/W, VPC-CW16FG, VPC-CW16FG/B, VPC-CW16FG/L, VPC-CW16FG/P, VPC-CW16FG/R, VPC-CW16FG/W, VPC-CW18FC/B, VPC-CW18FC/L, VPC-CW18FC/P, VPC-CW18FC/R, VPC-CW18FC/W, VPC-CW18FG/B, VPC-CW18FJ, VPC-CW18FJ/P, VPC-CW18FJ/R, VPC-CW18FJ/W, VPC-CW19FJ, VPC-CW19FJ/W, VPC-CW1AFJ, VPC-CW1AGG/B, VPC-CW1AHJ, VPC-CW1BGN/BU, VPC-CW1EFX/W, VPC-CW1FFX/L, VPC-CW1S1E, VPC-CW1S1E/B, VPC-CW1S1E/L, VPC-CW1S1E/P, VPC-CW1S1E/R, VPC-CW1S1E/W, VPC-CW1ZEG/BU, VPC-CW1ZEH/BU, VPC-CW21FX/B, VPC-CW21FX/L, VPC-CW21FX/R, VPC-CW21FX/W, VPC-CW25FG, VPC-CW25FG/B, VPC-CW25FG/P, VPC-CW25FG/W, VPC-CW26EC, VPC-CW26EC/B, VPC-CW26FG, VPC-CW26FG/B, VPC-CW26FG/L, VPC-CW26FG/W, VPC-CW26FG/R, VPC-CW26FG/F, VPC-CW26FH/P, VPC-CW26FH/R, VPC-CW26FH/W, VPC-CW26FX/B, VPC-CW28EC, VPC-CW28EC/B, VPC-CW28EC/L, VPC-CW28EC/P, VPC-CW28EC/R, VPC-CW28EC/W, VPC-CW28FG/B, VPC-CW28FJ/P, VPC-CW28FJ/R, VPC-CW28FJ/W, VPC-CW29FJ, VPC-CW29FJ/W, VPC-CW2AFJ, VPC-CW2AGG/B, VPC-CW2AHJ, VPC-CW2BGN/BU, VPC-CW2MFX/PU, VPC-CW2S1E, VPC-CW2S1E/B, VPC-CW2S1E/L, VPC-CW2S1E/P, VPC-CW2S1E/R, VPC-CW2S1E/W, VPC-CW2S3C, VPC-CW2S5C, VPC-CW2S5C CN1, VPC-CW2S5CCN1, VPC-CW2Z1E/B, VPC-F112FX/B, VPC-F115FG, VPC-F115FG/B, VPC-F115FM, VPC-F116FG, VPC-F116FGBI, VPC-F117FJ, VPC-F117FJ/W, VPC-F117HG, VPC-F117HG/B, VPC-F118FJ, VPC-F118FJ/W, VPC-F119FC, VPC-F119FC/B, VPC-F119FJ, VPC-F119FJ/B, VPC-F11AJF, VPC-F11AGJ, VPC-F11AHJ, VPC-F11C5E, VPC-F11JFX/B, VPC-F11M1E, VPC-F11M1E/H, VPC-F11MFX/B, VPC-F11S1E, VPC-F11S1E/B, VPC-F11Z1E, VPC-F11Z1E/B, VPC-F11ZHJ, VPC-F127FDB, VPC-F127FJ/W, VPC-F127HGBI, VPC-F128FJ/B, VPC-F129FJ/B, VPC-F12AFJ, VPC-F12AGJ, VPC-F12AHJ, VPC-F12E1E/H, VPC-F12E1E/W, VPC-F12F4E/H, VPC-F12JFX/B, VPC-F12KFX/B, VPC-F12M0E/B, VPC-F12M1E, VPC-F12M1E/H, VPC-F12S1E, VPC-F12S1E/B, VPC-F12XHX/B, VPC-F12Z1E, VPC-F12Z1E/B, VPC-F135FG, VPC-F135FG/B, VPC-F136FG/B, VPC-F137HG/B, VPC-F138FC/B, VPC-F138FJ/B, VPC-F139FJ/B, VPC-F13AFJ, VPC-F13AFX/B, VPC-F13AGJ, VPC-F13AHJ, VPC-F13BFX/B, VPC-F13C5E, VPC-F13E1E/H, VPC-F13E8E/H, VPC-F13JOE/H, VPC-F13L8E, VPC-F13L8E/H, VPC-F13M0E/B, VPC-F13M1E, VPC-F13M1E/H, VPC-F13M4E, VPC-F13M8E, VPC-

F13M8E/B, VPC-F13S0E, VPC-F13S0E/B, VPC-F13S1E/B, VPC-F13S8E, VPC-F13S8E/B, VPC-F13V5005B, VPC-F13WFX/BC, VPC-F13X5E, VPC-F13Z0E, VPC-F13Z0E/B, VPC-F13Z1E, VPC-F13Z1E/B, VPC-F13Z8E/B, VPC-F13ZHJ, VPC-F14FJ/B, VPC-F149FJ/B, VPC-F14AFJ, VPC-F14AGJ, VPC-F14AHJ, VPC-F14ZHJ, VPC-F215FDBI, VPC-F217HG, VPC-F217HG/B, VPC-F219FC, VPC-F219FC/B, VPC-F219FJ/B, VPC-F21AFJ, VPC-F21AGJ, VPC-F21AHJ, VPC-F21Z1E, VPC-F21Z1E/B, VPC-F21ZHJ, VPC-F224FDB, VPC-F226FJ/S, VPC-F227FJ/B, VPC-F229FJ/B, VPC-F22AJ, VPC-F22C5E, VPC-F22J1E, VPC-F22L1E, VPC-F22M0E, VPC-F22M1E, VPC-F22S1E, VPC-F22S1E/B, VPC-F235FDB, VPC-F235FW, VPC-F235FW/B, VPC-F236HG, VPC-F236HW, VPC-F236HW/B, VPC-F237, VPC-F237FJ/S, VPC-F237HG, VPC-F237HW, VPC-F237HW/B, VPC-F238FJ/B, VPC-F23AJ, VPC-F23C5E, VPC-F23L1E, VPC-F23M1E, VPC-F23P1E, VPC-F23Q1E, VPC-F23S1E, VPC-F23Z1E, VPC-F23Z1E/B, VPC-F244FDS, VPC-F247FJ/S, VPC-F248FJ/B, VPC-F249FJ/B, VPC-F24A, VPC-F24L1E, VPC-F24M1E, VPC-F24N1E, VPC-F24P1E, VPC-F24Q1E, VPC-M121ADP, VPC-M125, VPC-M125AG, VPC-M125AG/L, VPC-M125AG/P, VPC-M125AG/W, VPC-M125AGP, VPC-M125AW/L, VPC-M125JC/W, VPC-M126, VPC-M126AA/L, VPC-M126AA/P, VPC-M126AA/W, VPC-M126AG/L, VPC-M126AG/P, VPC-M126AG/W, VPC-M126AH/L, VPC-M126AH/P, VPC-M126AH/W, VPC-M128JC/L, VPC-M128JC/P, VPC-M129AJ/L, VPC-M129AJ/P, VPC-M129AJ/W, VPC-M12M1E/L, VPC-M12M1E/P, VPC-M12M1E/W, VPC-M13M1E/L, VPC-M13M1E/P, VPC-M13M1E/W, VPC-S111FM/S, VPC-S115EC, VPC-S115FG, VPC-S117GG, VPC-S117GGB, VPC-S118EC, VPC-S119FJ, VPC-S119FJ/B, VPC-S119GC, VPC-S11AFJ, VPC-S11AGJ, VPC-S11AHJ, VPC-S11AVJ, VPC-S11J7E, VPC-S11J7E/B, VPC-S11M1E, VPC-S11M1E/W, VPC-S11V9E, VPC-S11V9E/B, VPC-S11X8E/B, VPC-S11X9E, VPC-S11X9E/B, VPC-S123FGB, VPC-S125EC, VPC-S125FG, VPC-S128EC, VPC-S129FJ/B, VPC-S129FJ/S, VPC-S129GC, VPC-S12AFJ, VPC-S12AGJ, VPC-S12AHJ, VPC-S12AVJ, VPC-S12C7E/B, VPC-S12J1E/W, VPC-S12L9E/B, VPC-S12V9E/B, VPC-S12X9E, VPC-S12X9E/B, VPC-S133GN/B, VPC-S135EC, VPC-S135EC/B, VPC-S135EC/G, VPC-S135EC/P, VPC-S135FA/B, VPC-S135FG/W, VPC-S135FH/P, VPC-S136EC, VPC-S136EC/B, VPC-S136EC/G, VPC-S136EC/P, VPC-S136FA/B, VPC-S136FG/B, VPC-S137GA/B, VPC-S137GF/B, VPC-S137GG, VPC-S137GG/B, VPC-S137GH/B, VPC-S138EC, VPC-S138EC/B, VPC-S138EC/G, VPC-S138EC/P, VPC-S139FJ/B, VPC-S139FJ/P, VPC-S139FJ/S, VPC-S139GC, VPC-S139GC/B, VPC-S13AFG, VPC-S13AFG/B, VPC-S13AFG/G, VPC-S13AFG/P, VPC-S13AFG/W, VPC-S13AFH/B, VPC-S13AFH/W, VPC-S13AFJ, VPC-S13AGJ, VPC-S13AHJ, VPC-S13L8E, VPC-S13L8E/B, VPC-S13L9E/B, VPC-S13M1E, VPC-S13M1E/W, VPC-S13S9E, VPC-S13S9E/B, VPC-S13V9E/B, VPC-S13X8E, VPC-S13X9E/B, VPC-S149FJ/B, VPC-S149FJ/P, VPC-S149FJ/S, VPC-S14AFJ, VPC-S14AGJ, VPC-S14AHJ, VPC-W115XGP, VPC-W213AG/L, VPC-W213AG/P, VPC-W213AG/T, VPC-W213AG/W, VPC-W215AG/L, VPC-W216AG/T, VPC-W216AG/W, VPC-W218AGL, VPC-W21BAGZ, VPC-W21EAG/WI, VPC-Y115FG/S, VPC-Y115FGS, VPC-Y115FX/B, VPC-Y115FX/BI, VPC-Y115FXBI, VPC-Y118EC, VPC-Y118GX/BI, VPC-Y119FJ, VPC-Y119FJ/S, VPC-Y11AFJ, VPC-Y11AGJ, VPC-Y11AHJ, VPC-Y11AVJ, VPC-Y11M1E, VPC-Y11M1E/S, VPC-Y11S1E, VPC-Y11S1E/S, VPC-Y11V9E, VPC-Y11V9E/S, VPC-Y218EC/BI, VPC-Y218EC/G, VPC-Y218EC/L, VPC-Y218EC/P, VPC-Y218EC/R, VPC-Y219FJ/S, VPC-Y21AFJ, VPC-Y21AGJ, VPC-Y21AHJ, VPC-Y21AVJ, VPC-Y21EFX/B, VPC-Y21EFX/V, VPC-Y21S1E, VPC-Y21S1E/G, VPC-Y21S1E/L, VPC-Y21S1E/P, VPC-Y21S1E/SI, VPC-Y21SFX/R, VPC-Y22Z5008B, VPC-YA15EC/B, VPC-YA15EC/R, VPC-YA15FG, VPC-YA15FG/B, VPC-YA15FG/R, VPC-YA15FH/B, VPC-YA15FH/R, VPC-YA16EC/B, VPC-YA16EC/R, VPC-YA16FW, VPC-YA17GG, VPC-YA17GG/B, VPC-YA17GG/R, VPC-YA17GH/B, VPC-YA17GH/R, VPC-YA17GW, VPC-YA19FJ/B, VPC-YA1C5E, VPC-YA1V9E, VPC-YA2AJ, VPC-YB13KDS, VPC-YB15, VPC-YB15AG/G, VPC-YB15AG/P, VPC-YB15AG/S, VPC-YB15AH/G, VPC-YB15AH/P, VPC-YB15AH/S, VPC-YB15KXP, VPC-YB16, VPC-YB16KG/G, VPC-YB16KG/P, VPC-YB16KG/S, VPC-YB19KJ/G, VPC-YB19KJ/P, VPC-YB19KJ/S, VPC-YB1S1E, VPC-YB1S1E/S, VPC-YB29KJ/G, VPC-YB29KJ/P, VPC-YB29KJ/S, VPC-YB2M1E, VPC-YB33KDB, VPC-YB33KX/B, VPC-YB33KX/P, VPC-YB35JC, VPC-YB35KXS, VPC-YB36KG, VPC-YB36KGP, VPC-YB36KW, VPC-YB36KW/P, VPC-YB36KW/S, VPC-YB3V1E