

Link do produktu: <https://www.akcesoriapc.pl/kabel-usb-20-b-mini-canon-1-8m-digitus-ak-300108-018-s-p-306.html>

Kabel USB 2.0 B mini Canon 1,8m Digitus AK-300108-018-S



Cena brutto	6,90 zł
Cena netto	5,61 zł
Dostępność	Dostępny
Numer katalogowy	0079
Kod producenta	AK-300108-018-S
Kod EAN	4016032282907
Producent	no name

Opis produktu

Kabel USB 2.0 B mini typ CANON 1,8m

pozwała na podłączenie do portu USB aparatów cyfrowych, czy innych urządzeń peryferyjnych podłączanych przez port USB. Kabel z jednej strony posiada złącze męskie typu A, które podłącza się do gniazda USB w komputerze, a z drugiej złącze USB B mini (podłączany do urządzenia / aparatu) typu Canon.

Kabelek pasuje m.in. do następujących modeli aparatów/kamer:

CANON: PowerShot S300, PowerShot S330, PowerShot S400, PowerShot S410, PowerShot S500, PowerShot SD100, PowerShot S30, PowerShot S40, PowerShot S45, PowerShot S50, G3, G5, Pro 1, S1 IS, PowerShot A10, PowerShot A20, PowerShot A30, PowerShot A40, PowerShot A60, PowerShot A70, PowerShot A80, PowerShot A85, PowerShot A95, PowerShot A100, PowerShot A200, PowerShot A300, OPTURA 300, OPTURA Xi, OPTURA 20, Elura 70, Elura 65, Elura 60, Digital IXUS 300 (S300 ELPH), IXUS 330, IXUS 400, ZR90, ZR45mc, ZR50mc, ZR65mc, ZR70mc, EOS Digital Rebel, EOS D10

AIPTEK: PocketCam X, PocketCam 4000, PocketCam 4100M, Pocket DV4500, Pocket DV5900

ARGUS: DC3550, DC3510, DC3500

BLACKBERRY: 6210, 6230, 6280, 6510, 7210, 7230, 7280, 7510

BUSLINK: D-20-U2, D-40-U2, D-60-U2

DIGITREX: DSC-1300, DSC-2100, DSC-2102, DSC-3000, DSC-4500Z

FUJI: FinePix F10, FinePix S5000, FinePix S7000, FinePix A345, FinePix A350

HITACHI: DZMV380A, DZMV350A, DZMV230A, DZMV270A, DZMV200A

HP: PHOTOSMART 120, PHOTOSMART 120cse, PHOTOSMART 120V, PHOTOSMART 318, PHOTOSMART 318se, PHOTOSMART 320, PHOTOSMART 320v, PHOTOSMART 320xi, PHOTOSMART 433, PHOTOSMART 433v, PHOTOSMART 433xi, PHOTOSMART 435, PHOTOSMART 435v, PHOTOSMART 435xi, PHOTOSMART 612, PHOTOSMART 612Cxi, PHOTOSMART 620, PHOTOSMART 620v, PHOTOSMART 620xi, PHOTOSMART 635, PHOTOSMART 635v, PHOTOSMART 635xi, PHOTOSMART 715, PHOTOSMART 715xi, PHOTOSMART 715Cxi, PHOTOSMART 720, PHOTOSMART 720v, PHOTOSMART 720xi, PHOTOSMART 733, PHOTOSMART 733v, PHOTOSMART 733xi, PHOTOSMART 735, PHOTOSMART 735v, PHOTOSMART 735xi, PHOTOSMART 850, PHOTOSMART 850xi, PHOTOSMART 912, PHOTOSMART 912xi, PHOTOSMART 935, PHOTOSMART 935v, PHOTOSMART 935xi, PHOTOSMART 945, PHOTOSMART 945xi, M23, M305, M307, M407, R507, R607, R707, R717 Dock 8881, Dock 8886

SONY: Mavica MVC-FD92, MVC-FD97, MVC-FD100, MVC-FD200, MVC-CD200, MVC-CD250, MVC-CD300, MVC-CD400, Cybershot DSC-P1, DSC-P3, DSC-P5, DSC-P7, DSC-P8, DSC-P9, DSC-P20, DSC-P30, DSC-P31, DSC-P32, Cybershot DSC-P41, Cybershot DSC-P50, DSC-P51, DSC-P52, DSC-P71, DSC-P72, DSC-P73, DSC-P92, DSC-S75, DSC-S85, DSC-F707, DSC-F717, DSC-U10, DSC-U20, DSC-U30, DSC-U40, DSC-U40/B, DSC-U40/R, DSC-U40/S, DSC-U50, DSC-U60, Cybershot DSP-P5, DSP-P7, PowershotPRO1, CLIE PDA UX40, UX50

SAMSUNG: Digimax 101, Digimax 200, Digimax 201, Digimax 230, Digimax 240, Digimax 300, Digimax 340, Digimax 410, Digimax 420, SCD180, SCD23, SCD24, SCD27, SCD29, SCD33, SCD34, SCD39, SCD5000, SCD590, SCD86, SCL770, SCL870

POLAROID: PhotoMax PDC1050, PhotoMax PDC1075, PhotoMax PDC2150, PhotoMax PDC2350, PhotoMax PDC3350, PhotoMax PDC4350, ion 230, ion 230 Dock

PANASONIC: DMC-F7, DMC-FZ1, DMC-FZ1S, DMC-FZ10, DMC-FZ10K, DMC-LC5, DMC-LC5K, DMC-LC5S, DMC-LC20, DMC-LC33, DMC-LC40, DMC-L33, PV-GS2, PV-GS70, PV-GS50, PV-GS50S, PV-DV203, SV-AV100

OLYMPUS: C-50Z, C-720UZ, C-730UZ, C-740UZ, C-750UZ, C-4000Z, C-5050Z, D-520Z, D-550Z, D-560Z Stylus Digital 300,

400, 410, C-8080 Zoom, C-5060 Wide Zoom, C-5000 Zoom, C-5060 Zoom, C-5050 Zoom, C-50 Zoom, C-60 Zoom, C-4000 Zoom, C-720 Ultra Zoom, C-730 Ultra Zoom, C-740 Ultra Zoom, C-750 Ultra Zoom, C-765 Ultra Zoom, C-770 Ultra Zoom, D-580 Zoom, D-575 Zoom, D-565 Zoom, D-560 Zoom, D-550 Zoom, D-540 Zoom, D-520 Zoom, D-390, D-380

MINOLTA: DiMAGE E223, G400

NIKON: D100, CoolPix 2000

JVC: GRD93US, GRD90US, GRD72, GRD70US, GR-DVL510U, GR-DVL815U, GR-DVL915U, GR-DVL512U, GR-DVL520U, GR-DVL720U, GR-DVL725U, GR-DVL817U, GR-DVL820U, GR-DVL920U, GR-DVM96U

VIVITAR: Vivicam 3301, Vivicam 3315, Vivicam 3325, Vivicam 3345, Vivicam 3350, Vivicam 3355, Vivicam 3500, Vivicam 3555, Vivicam 3555T, Vivicam 3610, Vivicam 3625, Vivicam 3630, Vivicam 3632, Vivicam 3640, Vivicam 3650, Vivicam 3705, Vivicam 3715, Vivicam 3715A, Vivicam 3715B, Vivicam 3730, Vivicam 3735, Vivicam 3740, Vivicam 3746, Vivicam 3750, Vivicam 3755, Vivicam 3760, Vivicam 3765, Vivicam 3780, Vivicam 3805, Vivicam 3825, Vivicam 3826, Vivicam 3930, Vivicam 3935, Vivicam V25, Vivicam V55

Długość kabla - 1,8m, kolor kabla - czarny.

Uwaga! Jeśli Twój aparat nie jest wymieniony powyżej kabel kupujesz wyłącznie na własną odpowiedzialność - nie przyjmujemy reklamacji z tego tytułu. Kod PLU: __0127__