

Link do produktu: <https://www.akcesoriapc.pl/zasilacz-mitsu-19v-342a-40x135-65w-do-asus-p-4257.html>



## Zasilacz Mitsu 19v 3.42a (4.0x1.35) 65W do Asus

Cena brutto	<b>69,40 zł</b>
Cena netto	<b>56,42 zł</b>
Dostępność	<b>Dostępny</b>
Numer katalogowy	<b>5979</b>
Kod producenta	<b>ZM/AS19342E</b>
Kod EAN	<b>5902687188727</b>
Producent	<b>mitsu</b>

### Opis produktu

#### Zasilacz Mitsu 19v 3.42a (4.0x1.35) 65W do Asus

- **Producent:** Mitsu
- **Model:** ZM/AS19342E
- **Stan:** nowy
- **Wejście:** AC 100-240V
- **Wyjście:** 19V 3.42A
- **Moc:** 65W
- **Wtyk:** 4.0 x 1.35 mm
- **Wymiary:** 107 x 45 x 28 mm
- **Zabezpieczenie przed:** przepięciem, przegrzaniem, zwarcieniem, przeciążeniem prądowym
- **Certyfikat:** CE, FCC, RoHS
- **W zestawie:** zasilacz, kabel zasilający, instrukcja obsługi, karta gwarancyjna
- **Kabel zasilający:** 3 pin
- **Gwarancja:** 24 miesiące + 6 miesięcy\*\*dodatkowe 6 miesięcy po darmowej rejestracji produktu
- **Zamiennik:** 0A001-00043100, 0A001-00044600, 0A001-00045900, 0A001-00049200, 0A001-00049700, 0A001-00230300, 0A001-00237800, 0A001-00441200, 0A001-00441700, 0A001-00442900, 0A001-00444500, 0A001-00444700, 0A001-00445700, 0A001-00446000, 0A001-00446200, 0A001-00449800, 0A200-00021900, 90-XB3J00PW00080, 90-XB3NN0PW00010Y, ADP-65AW A, ADP-65AWA, ADP-65DW C, ADP-65DW Z, ADP-65DWC

#### Zgodny z:

#### Asus

A540,A540L,A540LA,A540LA-DM577D,A540LA-XX014R,A540LA-XX016D,A540LA-XX039D,A540LA-XX085T,A540LA-XX202T,A540LA-XX289R,A540LA-XX373T,A540LA-XX452R,A540LA-XX521R,A540LJ,A540LJ-34A92,A540LJ-34B92PB1,A540LJ-XX019T,A540LJ-XX414D,A540S,A540SA,A540SA-C3AHD,A540SA-DM538T,A540SA-XX029D,A540SA-XX083T,A540SA-XX117T,A540SA-XX123T,A540SC,A540SC-DM082T,A540SC-P3B91S,A540SC-P3B91SB1,A540SC-XX012T,A540SC-XX091T,A540Y,A540YA,A540YA-DM077T,A541,A541S,A541SA,A541SA-DM171T,A541SA-DM171T-BE,A541SA-XO086T,A541SA-XX153D,A541UV,A541UV-DM1511T,A553,A553M,A553MA,A553MA-XX095D,A553MA-XX1147D,A553MA-XX356H,A553MA-XX357H,A553MA-XX648D,A556,A556U,A556UA,A556UA-X0016D,A556UA-XO016D,A556UB,A556UB-XX190T,A556UB-XX191T,A556UF,A556UF-FX038T,A556UF-XX051D,A556UF-XX062D,A556UJ,A556UR,A556UV,ADP-65AW A,ADP-65JH DB,D453,D453M,D453MA,D453MA-WX102H,D540,D540Y,D540YA,D541,D541S,D541SC,D553,D553M,D553MA,D553MA-HH01,D553MA-XX190H,D553MA-XX191H,E402YA,F302,F302L,F302LA,F302LJ,F540,F540L,F540LA,F540LA-DM022T,F540LA-DM757T,F540LA-XX030T,F540LA-XX059T,F540LA-XX060D,F540LA-XX069T,F540LA-XX070T,F540LA-XX34,F540LJ,F540LJ-DM027T,F540LJ-DM161T,F540LJ-DM166T,F540LJ-XX028T,F540LJ-XX

029T,F540LJ-XX034T,F540LJ-XX048D,F540LJ-XX048T,F540LJ-XX095T,F540LJ-XX213T,F540S,F540SA,F540SA-DM042T,F540SA-DM043T,F540SA-DM065T,F540SA-XX073D,F540SA-XX087T,F540SA-XX102T,F540SA-XX103T,F540SA-XX110T,F540SA-XX125T,F540SA-XX145T,F540SA-XX183T,F540SA-XX220T,F540SC,F540SC-DM005T,F540SC-XX008T,F540SC-XX030T,F540SC-XX068T,F540Y,F540YA,F540YA-XO086T,F540YA-XX078T,F541,F553,F553M,F553MA,F553MA-CJ743H,F553MA-HH01T,F553MA-HH24TQ,F553MA-SX361B,F553MA-XX1151T,F556,F556U,F556UA,F556UA-AS54,F556UA-EH71,F556UA-XO062T,F556UA-XO094T,F556UA-XO062T,F556UA-XO094T,F556UB,F556UB-DM052T,F556UB-DM060T,F556UB-DM061T,F556UB-DM068T,F556UB-DM139T,F556UF,F556UF-DM061T,F556UF-DM064T,F556UF-DM065T,F556UF-DM066T,F556UJ,F556UJ-DM026T,F556UJ-X0010T,F556UJ-XO010T,F556UJ-XX021T,F556UJ-XX024T,F556UQ,F556UQ-DM142T,F556UR,F556UR-X0006T,F556UR-X0037T,F556UR-XO006T,F556UR-XO037T,F556UV,F556UV-XX110T,F756,F756U,F756UA,F756UA-TY021T,F756UA-TY031T,F756UA-TY037T,F756UB,F756UB-TY004T,F756UB-TY005T,F756UJ,F756UJ-T4027T,F756UJ-T4028T,F756UX,F756UX-T4034T,F756UX-T4035T,F756UX-T4061T,F756UX-T7013T,K540,K540L,K540LA,K540LA-XX035D,K540LA-XX041D,K540LA-XX083T,K540LA-XX089T,K540LA-XX143D,K540LA-XX632T,K540LA-XX707T,K540LJ,K540LJ-XX032D,K540LJ-XX032T,K540LJ-XX035D,K540LJ-XX121D,K540LJ-XX122D,K540LJ-XX455T,K540LJ-XX519T,K556,K556U,K556UA,K556UB,K556UB-XX023D,K556UB-XX175D,K556UB-XX178D,K556UF,K556UJ,K556UJ-XX032D,K556UJ-XX109T,K556UQ,K556UR,M509DJ,M509DL,N402NA,Q324,Q324U,Q324UA,Q324UAK,Q504,Q504U,Q504UA,Q551,Q551L,Q551LB,Q551LN,R515,R515L,R515LA,R515M,R515MA,R515MA-BING-SX569B,R515MA-RH01,R515MA-SX569B,R515MA-XX553H,R515MA-XX764H,R515S,R515SA,R515SA-XX247T,R515SA-XX248T,R540L,R540LA,R540LA-R531,R540LA-XX020,R540LA-XX020D,R540LA-XX020T,R540LA-XX087T,R540LA-XX092T,R540LA-XX325T,R540LA-XX342,R540LA-XX411T,R540LA-XX544T,R540LA-XX722T,R540LJ,R540LJ-DM045T,R540LJ-DM239T,R540LJ-GK535T,R540LJ-XX004,R540LJ-XX004T,R540LJ-XX253T,R540LJ-XX336,R540LJ-XX337T,R540LJ-XX338,R540LJ-XX338T,R540LJ-XX339T,R540LJ-XX340,R540LJ-XX340T,R540LJ-XX461T,R540S,R540SA,R540SA-DM267T,R540SA-RS01,R540SA-XX022T,R540SA-XX040,R540SA-XX040D,R540SA-XX040T,R540SC,R540SC-XX007D,R540SC-XX019T,R540SC-XX031T,R540SC-XX032T,R540SC-XX086D,R540SC-XX087D,R540U,R540UB,R540UV,R540Y,R540YA,R540YA-XO112T,R540YA-XX065T,R540YA-XX065T-BE,R541,R541U,R541UA,R553,R553L,R557U,R557UQ,R558,R558U,R558UA,R558UA-DM121T,R558UB,R558UB-DM108T,R558UF,R558UF-X0044D,R558UF-X0044T,R558UF-XO044D,R558UF-XO044T,R558UJ,R558UJ-XX069T,R558UV,UX30,VIVOBOK U38,VIVOBOK U38DT,VIVOBOK U38N,VIVOBOK U38N-C4004H,X102B,X302,X302L,X302LA,X302LJ,X302U,X302UA,X302UJ,X302UV,X330FL,X330FN,X403,X403M,X403MA,X403MA-WX154D,X409DJ,X409FB,X409FJ,X409FL,X409UB,X409UJ,X412FL,X432FL,X441UB,X453,X453M,X453MA,X453MA-WX122B,X453MA-WX216D,X453MA-WX217D,X453MA-WX219D,X453MA-WX238D,X453MA-WX300T,X453MA-WX315B,X453MA-WX428D,X503,X503M,X503MA,X503MA-SX840D,X503MA-XX313D,X503S,X503SA,X507UB,X507UF,X509FB,X509FJ,X509FL,X509UB,X509UJ,X515JA,X531FL,X540,X540BP,X540L,X540LA,X540LA-SI30205P,X540LA-XX002D,X540LA-XX002T,X540LA-XX003T,X540LA-XX004T,X540LA-XX013T,X540LA-XX037T,X540LA-XX072T,X540LA-XX312T,X540LA-XX821,X540LJ,X540LJ-DM311T,X540LJ-XX001D,X540LJ-XX001T,X540LJ-XX002,X540LJ-XX002T,X540LJ-XX011D,X540LJ-XX014D,X540LJ-XX016D,X540LJ-XX022D,X540LJ-XX043T,X540LJ-XX060T,X540LJ-XX090D,X540LJ-XX229D,X540LJ-XX250T,X540LJ-XX357T,X540S,X540SA,X540SA-BPD0602V,X540SA-RBPDN09,X540SA-RS01-CB,X540SA-SCL0205N,X540SA-XX002D,X540SA-XX002T,X540SA-XX004D,X540SA-XX006T,X540SA-XX009T,X540SA-XX012T,X540SA-XX018D,X540SA-XX048T,X540SA-XX063T,X540SA-XX095T,X540SA-XX333T,X540SC,X540SC-DM009D,X540SC-DM076T,X540SC-XX002D,X540SC-XX006D,X540SC-XX010D,X540SC-XX014D,X540SC-XX025D,X540SC-XX040D,X540SC-XO041T,X540SC-XX083D,X540UB,X540YA,X540YA-DM075T,X540YA-DM085T,X540YA-XO033T,X540YA-XX016T,X540YA-XX055T,X541,X541S,X541SA,X541SA-DM031T,X541SA-GK054T,X541SA-OP2-CB,X541SA-XO041D,X541SA-XO056D,X541SA-XO056T,X541SA-XO122D,X541SA-XO137,X541SA-XO287T,X541SA-XX012T,X541SA-XX107T,X541SA-XX107T-BE,X541SA-XX204T,X541SA-XX204T-BE,X541SC,X541SC-GK006T,X541SC-XO011T,X541SC-XX034T,X541U,X541UA,X541UA-DM014T,X541UA-DM015T,X541UA-DM046T,X541UA-DM139D,X541UA-DM167T,X541UA-DM233T,X541UA-WB51,X541UA-XO112D,X541UA-XO129T,X541UA-XO009T,X541UA-XX009T-BE,X541UA-XX124T,X541UA-XX133D,X541UA-XX133R,X541UA-XX159T,X541UA-XX202T,X541UA-XX264T,X541UJ,X541UV,X541UV-6198DU,X541UV-DM107T,X541UV-DM120T,X541UV-DM178T,X541UV-DM297T,X541UV-XO029D,X541UV-XO085T,X541UV-XO241T,X541UV-XX039D,X541UV-XX039T,X541UV-XX041T,X541UV-XX067T,X541UV-XX067T-BE,X541UV-XX068T,X541UV-XX068T-BE,X541UV-XX104D,X541UV-XX143D,X541UV-XX151T,X543BP,X543UB,X545FB,X545FJ,X553,X553M,X553MA,X553MA-DB01,X553MA-RB01,X553MA-SX284B,X553MA-SX455B,X553MA-SX870H,X553MA-SX880H,X553MA-XX490D,X553MA-XX490T,X556,X556U,X556UA,X556UB,X556UF,X556UJ,X556UQ,X556UQ-DM077T,X556UQ-X0075T,X556UQ-XO075T,X556UR,X556UV,X556UV-XO022T,X712DK,X712FB,X303L,

#### seria Zenbook

U38DT, U500V, U500VZ, UX301, UX301L, UX301LA, UX302, UX302L, UX302LA, UX302LG, UX303, UX303L, UX303LA, UX303LB, UX303LN, UX303U, UX303UA, UX303UB, UX305, UX305C, UX305CA, UX305F, UX305FA, UX305L, UX305LA, UX305U, UX305UA, UX306, UX306U, UX306UA, UX310, UX310U, UX310UA, UX310UF, UX310UQ, UX31K, UX31LA, UX32L, UX32LN, UX330, UX330C, UX330CA, UX330U, UX330UA, UX360, UX360C, UX360CA, UX360U, UX360UA, UX360UAK, UX390, UX390U, UX390UA, UX410, UX410U, UX410UA, UX410UF, UX410UQ, UX42V, UX42VS, UX430, UX430U, UX430UA, UX430UN, UX430UQ, UX461UN, UX50, UX510, UX510U, UX510UW, UX510UX, UX52, UX52A, UX52V, UX52VS, UX560, UX560U, UX560UA, UX560UQ, UX560UX, UX434F,

#### seria Zenbook Prime

UX32V, UX32VD, UX42V, UX42VS, UX52VS,

#### seria Vivobook

E402S, E502N, E502NA, K533J, U38, X430FN,

#### seria Transformer Book Flip

TP300LJ, TP300LJ-DW024H,

*seria VivoBook S14*

*S410UN, S430UA, S430UN, X411UF, X430UF,*

*seria ZenBook 14*

*UM431D, UM431DA, UM433, UM433D, UM433DA, UM433I, UM433IQ, UX431FA, UX431FL, UX431FN, UX433FA, UX433FN, UX434FL,*

*seria ZenBook 13*

*UX331UN, UX333FN, UX334FL,*

*seria ZenBook Flip 13*

*UX362FA,*

*seria ZenBook Flip 14*

*TP410UR, UX461FN, UX461UA, UX461UN,*

*seria ZenBook Edition 30*

*UX334FL,*

*seria VivoBook 15*

*X510QR, X512DK, X512FB, X512FJ, X512FL, X512UB, X512UF, X540UV,*

*seria VivoBook S13*

*S330UA, X330UN,*

*seria VivoBook S15*

*S510UN, S510UQ, S530UN, X530FN, X530UF, X530UN,*

*seria VivoBook Flip 14*

*TP410UA, TP410UF,*

*seria VivoBook 14*

*UX331FN, X411UN, X411UQ, X412DK, X412FJ, X412UB, X412UF,*

*seria NovaGo*

*TP370QL,*

*seria VivoBook Flip 15*

*TP510UF, TP510UQ,*

*seria ZenBook Flip*

*UX561UN,*

*Huawei*