Dane aktualne na dzień: 29-11-2026 00:01

Link do produktu: https://www.akcesoriapc.pl/bateria-movano-do-makita-bl1830-bl1850-3000-mah-p-7403.html



Bateria Movano do Makita BL1830 BL1850 (3000 mAh)

Cena brutto	**114,00 zł**
Cena netto	**92,68 zł**
Dostępność	**Dostępny**
Numer katalogowy	**9608**
Kod producenta	**BW/MA-BL1850LED-3**
Kod EAN	**5904162457229**
Producent	**Movano**

Opis produktu

Bateria Movano do Makita BL1830, BL1850 (3000 mAh)

- **Producent**: Movano
- **Model**: BW/MA-BL1850LED-3
- **Stan**: nowy
- **Pojemność**: 3000 mAh (54 Wh)
- **Napięcie**: 18V
- **Rodzaj baterii**: litowo-jonowa
- **Ilość ogniw**: 10 ogniw Li-Ion
- **Zabezpieczenie przed**: przepięciem, przegrzaniem, zwarciem, przeciążeniem prądowym, głębokim rozładowaniem oraz przeładowaniem
- **Certyfikat**: CE, FCC, RoHS
- **Wskaźnik led**: TAK
- **W zestawie**: bateria, instrukcja obsługi, karta gwarancyjna
- **Gwarancja**: 24 miesiące (obudowa i elektronika)12 miesięcy (pojemność ogniw)
- **Zamiennik**: 194204-5, 194205-3, 194230-4, 194309-1, 197265-04, 197265-4, 197280-8, 197422-4, BL1815, BL1820, BL1830, BL1830B, BL1835, BL1840, BL1840B, BL1845, BL1850, BL1850B, BL1860, BL1860B, BL1890, BL1890B, LXT400, XRU02Z

Zgodny z:

Makita

192898-0,45DRFXW,50DRFX,6936FDWDE,BBO180,BBO180Z,BCF,BCF201,BCF201Z,BCL,BCL180,BCL180F,BCL180W,BCL180Z,BCL180ZW,BCL182,BCL182Z,BCS,BCS550,BCS550F,BCS550RFE,BCS550Z,BDA,BDA350,BDA350F,BDA350RFE,BDA350Z,BDA351,BDA351RFE,BDA351Z,BDF,BDF450,BDF451,BDF451RFE,BDF451Z,BDF452,BDF452RFE,BDF452RHE,BDF452SHE,BDF452Z,BDF453RHE,BDF453SHE,BDF453Z,BDF454F,BDF454RFE,BDF454Z,BDF456RFE,BDF456Z,BDF458,BFR,BFR550,BFR550F,BFR550L,BFR550RFE,BFR550Z,BFR550ZX,BFR750,BFR750F,BFR750L,BFR750RFE,BFR750Z,BFS,BFS450,BFS450F,BFS450RFE,BFS450Z,BFS451RFE,BFS451Z,BGA,BGA402RFE,BGA402Z,BGA452,BGA452F,BGA452RFE,BGA452Z,BGD800,BGD800RFE,BGD800Z,BGD801,BGD801RFE,BGD801Z,BHP,BHP450,BHP451,BHP451RFE,BHP451SFE,BHP451Z,BHP452,BHP452HW,BHP452RFE,BHP452SHE,BHP452Z,BHP453,BHP453RFE,BHP453RHE,BHP453RHEX,BHP453SHE,BHP453Z,BHP454,BHP454F,BHP454RFE,BHP454Z,BHP456RFE,BHP456RFE3,BHP456RFWX,BHP456Z,BHP458,BHR,BHR202,BHR202F,BHR202RFE,BHR202RFE3,BHR202RFWX,BHR202Z,BHR240,BHR240Z,BHR241,BHR241F,BHR241RFE,BHR241Z,BHR242RFE,BHR242RFEV,BHR242Z,BHR243RFE,BHR243RFEV,BHR243Z,BHS630RFE,BHS630Z,BJN,BJN161,BJR,BJR181,BJR181F,BJR181RF,BJR181RFE,BJR181X,BJR181X1,BJR181Z,BJR182,BJR182F,BJR182X,BJR182Z,BJS,BJS101RFE,BJS130,BJS130F,BJS130RFE,BJS130Z,BJS161,BJS161F,BJS161RFE,BJS161Z,BJV,BJV180,BJV

180F,BJV180RF,BJV180RFE,BJV180Z,BKP180,BKP180RF,BKP180RFE,BKP180Z,BL1815,BLS713RFE,BML SERIES.,BML SERIES.XDT04CW,BML184,BML185,BML185 FLASHLIGHT,BML185W,BML186,BML800,BML801,BMR050,BMR100W,BO180D,BO180DRF,BO180DZ,BPB180,BPB180F,BPB180Z,BPJ140,BPJ180,BPT351,BPT351RFE,BPT351Z,BSS501,BSS501F,BSS501RFE,BSS501Z,BSS610,BSS610F,BSS610RF,BSS610RFE,BSS610SFE,BSS610X2,BSS610Z,BSS611F,BSS611X,BSS611Z,BST221F,BST221RFE,BST221X,BST221Z,BTD129,BTD129RFE,BTD129SHE,BTD129Z,BTD140,BTD140RFE,BTD140SFE,BTD140Z,BTD141,BTD141Z,BTD142HW,BTD142RHE,BTD142SHE,BTD142Z,BTD144,BTD144RFE,BTD144Z,BTD145RFE,BTD145Z,BTD146D,BTD146RFE,BTD146SHE,BTD146Z,BTD147,BTDW251Z,BTL061,BTL061F,BTL061RFE,BTL061Z,BTL063,BTL063F,BTL063Z,BTM50,BTM50RFE,BTM50Z,BTM50ZX5,BTP140,BTP140F,BTP140RFE,BTP140Z,BTP141,BTP141RFX2,BTP141Z,BTW251,BTW251F,BTW251FX1,BTW251RFE,BTW251W,BTW251X,BTW251Z,BTW251ZX1,BTW253,BTW253F,BTW253RFE,BTW253Z,BTW450,BTW450F,BTW450FX1,BTW450RFE,BTW450X,BTW450Z,BTW450ZX,BTW450ZX1,BTW451,BUB182,BUB182F,BUB182Z,BUC122RFE,BVC350Z,BVF154RF,BVR350,BVR350F,BVR350Z,BVR450,BVR450F,BVR450RFE,BVR450Z,BVR850,BVR850F,BVR850Z,CF201DZ,CF201DZW,CL180FD,CL180FDRFW,CL180FDZW,CL182FD,CL182FDRFW,D145DRFX,DA350DRF,DBN500RFE,DBN600Z,DBO180RTJ,DBO180Z,DBS180RTJ,DBS180Z,DCB200A,DCE090T2X1,DCE090ZX1,DCF102Z,DCF203Z,DCF300Z,DCG180RF,DCG180RFX,DCG180Z,DCG180ZX,DCJ205Z2XL,DCJ205Z3XL,DCJ205ZL,DCJ205ZXL,DCJ206Z2XL,DCJ206Z3XL,DCJ206ZL,DCJ206ZXL,DCL180Z,DCL180ZB,DCL182Z,DCL182ZB,DCL184RF,DCL184Z,DCL280FZ,DCL282FZ,DCL500Z,DCL501Z,DCO180Z,DCO181Z,DCS552RTJ,DCS552Z,DCS553RTJ,DCS553Z,DCU180Z,DCV202ZL,DCV202ZXL,DDA350RFJ,DDA350Z,DDA460Z,DDF083RFE,DDF083RFJ,DDF083Z,DDF451RTJ,DDF451Z,DDF453RFE,DDF453Z,DDF458RTJ,DDF458Z,DDF481RTJ,DDF481Z,DDF482RFJ,DDF482Z,DDF483RFJ,DDF483Z,DDF484RFJ,DDF484Z,DDF485RFJ,DDF485Z,DDG460T2X7,DDG460ZX7,DEADML185,DEADML186,DEADML800,DEADML801,DEADML801X,DEADML802,DEADML805,DEADML806,DEADML808,DF454D,DF454DRFX,DF454DZ,DF457DWE,DF457DWLE,DF458DRFX,DF458DZ,DFJ201Z2XL,DFJ201ZL,DFJ201ZM,DFJ201ZS,DFR550RFE,DFR550Z,DFS250Z,DFS451RFJ,DFS451Z,DFS452RFE,DFS452Z,DGA452RTJ,DGA452Z,DGA504RTJ,DGA504ZJ,DGA506RTJ,DGA506ZJ,DGA513RTJ,DGA513ZJ,DGA514RTJU,DGA514ZJU,DGA517RTJ,DGA517ZJ,DGA518RTJU,DGA518ZJU,DGA700Z,DGA900PT2,DGA900Z,DGA901T2U1,DGA901ZUX1,DGD800RTJ,DGD800Z,DHK180ZJ,DHP451RTJ,DHP451Z,DHP453RFE,DHP453SYEX,DHP453Z,DHP458RTJ,DHP458Z,DHP481RTJ,DHP481Z,DHP482RFJ,DHP482Z,DHP483RFJ,DHP483Z,DHP484RFJ,DHP484Z,DHP485RFJ,DHP485Z,DHR171RTJ,DHR171Z,DHR182RTJ,DHR182TWJU,DHR182Z,DHR182ZU,DHR241RTJ,DHR241Z,DHR242RTJ,DHR242Z,DHR243RTJ,DHR243Z,DHR280PT2J,DHR280Z,DHR281PT2J,DHR281Z,DHR282ZU,DHR283T2JU,DHR283ZU,DHR400PT4U,DHR400ZKU,DHS630RTJ,DHS630Z,DHS660RTJ,DHS660ZJ,DHS661RTJU,DHS661ZJU,DHS680RTJ,DHS680Z,DHS710PT2J,DHS710Z,DHS782PT2J,DHS782Z,DHS783T2JU,DHS783ZU,DHS900ZU,DJN161RFJ,DJN161Z,DJR183RTJ,DJR183Z,DJR186RTE,DJR186Z,DJR187RTE,DJR187Z,DJR188RTJ,DJR188Z,DJR360Z,DJS130RFE,DJS130Z,DJS161RFJ,DJS161Z,DJV180RTJ,DJV180Z,DJV181RTJ,DJV181Z,DJV182RTJ,DJV182Z,DKP180RTJ,DKP180Z,DKP181RTJ,DKP181Z,DKP181ZU,DLM382PT2,DLM382Z,DLM432PT2,DLM432Z,DLM460PT2,DLM460Z,DLM462PT4,DLM462Z,DLM530PT4,DLM530Z,DLM532PT4,DLM532Z,DLM533PT4,DLM533Z,DLS111ZU,DLS211ZU,DLS600Z,DLS714NZ,DLW140Z,DLX2211TJ,DLX2220TJ,DLX3078TX1,DLX3089T,DLX4093,DLX4104TJ1,DLX6043T,DML802,DML809,DML810,DML811,DML812,DML815,DMP180Z,DMR107,DMR108,DMR110,DPB181RTE,DPB182Z,DPB183Z,DPB184Z,DPJ180RFJ,DPJ180Z,DPO500Z,DPO600RTE,DPO600Z,DPP200ZK,DPT353Z,DRC200Z,DRS780Z,DRT50RTJX2,DRV150RFJ,DRV150ZJ,DRV250RFJ,DRV250ZJ,DSC102Z,DSC121ZKX1,DSC163ZK,DSC251RT,DSC251ZK,DSD180RFJ,DSD180Z,DSL800RTEU,DSL800ZU,DSP600ZJ,DSP601ZJU,DSS610RTJ,DSS610Z,DST112Z,DST221RFJ,DST221Z,DTD152Z,DTD153RFJ,DTD153Z,DTD154RTJ,DTD154Z,DTD155RFJ,DTD155Z,DTD156RTJ,DTD156Z,DTD171RTJ,DTD171Z,DTL061RT1J,DTL061Z,DTM50RFJ,DTM50Z,DTM50ZX1,DTM51RFJX1,DTM51Z,DTM51ZX1,DTP141RTJ,DTR180ZJ,DTS141RTJ1,DTS141Z,DTW1001Z,DTW1002RTJ,DTW1002Z,DTW180RTJ,DTW180Z,DTW181RTJ,DTW181Z,DTW190RFJ,DTW251Z,DTW285RTJ,DTW300RTJ,DTW300Z,DTW301RTJ,DTW301Z,DTW450RTJ,DTW450Z,DTW700RTJ,DTW700Z,DTW701RTJ,DTW701Z,DUB182,DUB182Z,DUB184RT,DUB184Z,DUB186RT,DUB361Z,DUB362Z,DUB363ZV,DUC122RTE,DUC122Z,DUC254CZ,DUC254Z,DUC302Z,DUC306PT2B,DUC306ZB,DUC353Z,DUC355PT2,DUC355Z,DUC356PT2B,DUC356ZB,DUC406PT2B,DUC406ZB,DUH483RT,DUH483Z,DUH523RF,DUH523Z,DUH551PT2,DUH551Z,DUH601PTE,DUH601Z,DUH602RT,DUH602Z,DUH604SRG,DUH604SRGE,DUH604SZ,DUH651Z,DUH751PTE,DUH751Z,DUH754SRG,DUH754SRGE,DUH754SZ,DUM604SYX,DUM604ZX,DUN500WRGE,DUN500WZ,DUN600LRGE,DUN600LZ,DUP361PT2,DUP361Z,DUP362PT2,DUP362Z,DUR181SY,DUR181Z,DUR187LZ,DUR189RFE,DUR189Z,DUR190LRT3,DUR190LZX3,DUR190UZX3,DUR191LRT3,DUR191LZX3,DUR191URT3,DUR191UZX3,DUR368APT2,DUR368AZ,DUR368LPT2,DUR368LZ,DUR369APT2,DUR369AZ,DUR369LZ,DUT130Z,DUX18Z,DUX18ZX1,DUX60Z,DUX60ZM4,DVC150LZ,DVC152LZ,DVC154LZX,DVC155LZX2,DVC157LZX3,DVC261ZX11,DVC265ZXU,DVC350Z,DVC560PT2,DVC560Z,DVC660Z,DVC665ZU,DVC750LZX1,DVC860LZ,DVC862LZ,DVC864LZX,DVC865LZX3,DVC867LZX4,DVP180RT,DVP180Z,DVR450RTE,DVR850RTE,DWD181ZJ,DWR180RA,DWR180Z,DWT310ZK,FXBDF452RFE,GA402DRF,GA402DZ,GD800DRF,GD800DZ,HP451RFE,HP454D,HP454DRFX,HP454DZ,HP458DRFX,HP458DZ,HR202D,HR202DRFX,HR202DZK,HR242DRFX,HR242DRFXV,HS630DRFX,HS630DRFXW,HS630DZ,HS630DZW,JR120D,JR120DRF,JR120DZK,JR182DRF,JR182DZK,JV180DRF,JV183DWE,JV183DZ,KP180DRF,KP180DZ,L182FD,LXCU01,LXCU01Z,LXCV02Z,LXCV02Z1,LXDG01,LXDG01Z,LXDG01Z1,LXDT01,LXDT01Z,LXDT01Z1,LXDT04Z,LXDT04Z1,LXDT06Z,LXDT08Z,LXFD01,LXFD01CW,LXFD01Z,LXJP02,LXJP02Z,LXLC01Z,LXLC01Z1,LXLM01W,LXLM03,LXLM04,LXNJ01,LXPH01,LXPH01C1,LXPH01Z,LXPH03Z,LXPH05,LXPH05Z,LXPK01,LXPK01Z,LXPK01Z1,LXRU02,LXSF01,LXSF01Z1,LXSL01,LXSL01Z,LXSL01Z1,LXTP01,LXTP01Z,LXTP01Z1,LXWT01,LXWT01Z,ML184,ML184 FLASHLIGHT,ML185,ML800,ML801,MR050,MR100,MR100W,MUH263DZ,MUH401DRF,MUH401DZ,MUH461DRF,MUH461DZ,MUM168DRF,MUM168DZ,MUR181DRF,MUR181DZ,MUS104DSH,MUS104DZ,MUS154DSH,MUS154DZ,PB108D,PB108DRFX,PB108DZ,PB180DRFX,PJ180DRF,PT351D,PT351DRF,PT351DZK,SC162DRF,STEXML187,TD127DWE,TD140D,TD144D,TD144DRFX,TD144DZ,TD145DRFXB,TD145DRFXL,TD145DRFXP,TD146DRFP,TD146DRFX,TD146DRFXB,TD146DRFXL,TD146DRFXW,TD146DZ,TD147DRFX,TD147DZ,TD251DRFX,TD251DZ,TL061DRF,TM50DRF,TP140DRFX,TP141DRFX,TP141DZ,TW251D,TW251DRFX,TW450DR,TW450DRBJS130RFE,TW450DRFX,UB182D,UB182DRF,UB182DZ,UB183D,UC122D,VR350D,VR350DRFX,VR350DZ,VR450D,VR450DRFX,VR450DZ,W251DRFX,W450DR,XA001Z,XAD01Z,XAD02Z,XAG03M/Z,XAG03MZ,XAG03Z,XAG06MZ,XAG06Z,XBP01Z,XBP02Z,XDT01,XDT01Z,XDT04CW,XDT04Z,XDT06Z,XDT08,XDT08Z,XDT09M,XDT09Z,XFD01CW,XFD01Z,XFD03Z,XFD07M,XFD07MZ,XFD07Z,XGC01Z,XGC01ZB,XLC02ZW,XLT01Z,XLT02Z,XMT03Z,XNJ01Z,XOB01Z,XOC01Z,XPH01Z,XPH03Z,XPH06Z,XPH07Z,XRF01Z,XRH011X,XRH01ZVX,XRH03Z,XRH04Z,XRH04ZZ,XRH05Z,XRJ01Z,XRJ03Z,XRM02W,XRM03B,XRM04B,XRV01,XRV01Z,XRV02,XRV02Z,XSC01Z,XSF01Z,XSF03M,XSF03Z,XSH01Z,XSH03MZ,XSH03Z,XSJ01Z,XSS01Z,XSS02Z,XSS03Z,XST01M,XST01Z,XTS01Z,XVJ02Z,XVJ03Z,XWT01Z,XWT02M,XWT02Z,XWT04Z,XWT05,XWT05Z,XWT06Z,Z,